

APEIRON'S

Marble Countertop/Vanities Resurface & Polishing Procedures

Step 1—Scratch Removal Procedures

Apply a liberal amount of water.

With a low speed hand held machine hone the surface with **Apeiron's OCP 3" Disk**.

Honing time: Marble - 30 seconds per sq. ft. Keep wet at all times.

Remove the slurry and rinse with **Apeiron's Stone Wash**. Inspect to ensure scratches have been removed.



Step 2—Wet Polishing

Apply 1 oz of Apeiron's **Wet Polish** to the stone.

Apply 4 oz of water to the polishing powder and buff with a 7" white pad.

Continue to buff for 30 seconds per sq ft. Keeping the surface wet.

Work a small area at a time. Remove slurry and wipe dry with a soft cloth. Allow stone to dry completely before applying **Stone Paste**.



Repeat application if higher gloss is desired

Step 3— Application of Stone Paste

Apply a thin amount of **Stone Paste** with a soft cloth or pad in a circular motion.

Press firmly to push the paste into pores. Allow to dry for 10-15 minutes.

When surface is completely dry, buff with a fine grade steel wool pad.

Because of its particular composition this product achieves excellent gloss & Protection.



Repeat application if higher gloss is desired